

How to set MSW Setting support Japanese Character (mCP2/3)

Change Memory Switch Setting with mCollection Printer Utility on PC

1. Download driver utility from http://www.starmicronics.com/support/ type and select printer as below.



2. Click Download in "Star Windows Software Full" and install it. (Please do not connect with printer during install program)

Storrers & Manuals		Drives & Manuale 🗸
	Receipt Printers	
and the second se	14	Drivers Manuals Help Articles Other Downloads
		Star Windows Software Full Wrotes 11(3-1-41), Wrotes 10(32)(4-141) Star Windows Software



3. Connect printer mC-Print2/3 to PC by USB Cable then open Printer Utility and select which printer you want to setting then click next



4. Select USB model and click Done then enter your printer name and click OK

\frown	Printer Connection Wiz	ard	
	First choose your interface type then configure its connection settings.		
	USB Ethernet	USB connection settings	
MCP31	Bluetooth	Choose the Windows Printer Queue associated with your printer.	
Current Connection		Ota-MOD21 (Mindawa Drinter Overwa)	
MCP31 StarPRNT Mode USB Star MCP31		Star MCP31 (Windows Printer Queue) V Refresh	
	Printer Utility		
	Enter a name	for this printer connection.	
Connection Manager		ОК	
New Connection 2 \sim	MCP31-USB:Star M	CP31 Cancel	



6. Click Print Setting and wait Loading data...

\sim	Utility Functions
	<u>Windows Printer Queue Management</u> This function will allow for the installing and management of printer queues for the windows printer spool system.
MCP31	Star Micronics Cloud Enable retailers to engage with customer more effectively. Printer Settings Use this function to configure your printer's settings and fine tune its operation.
MCP31 StarPRNT Mode USB Star MCP31	Barcode Reader Settings Use this function to configure your barcode reader's settings and fine tune its operation. Troubleshooting
<u>Check</u> Change	Use this function to check and troubleshoot your printer by sending it a variety of diagnostic print patterns.
Connection Manager MCP31-USB:Star MC 🗸	OPOS This function allows you to register and configure OPOS POSPrinter, CashDrawer, Scanner, LineDisplay and ToneIndicator devices.
<u>Rename</u> <u>Delete</u> Create New	Logo Store Use this to store your logos and images into the printer. This is often useful in terms of deployment and also in terms of print speed.
	Firmware Update Use this functin to update your pinter's firmware.

7. Change 'Asian Character = Double Byte Character Set (DBCS)'

				_
\frown	Utility Functions > Printer Settings			
$\langle \rangle$	Category All	✓ * : Default Option		
	ASB (Bluetooth)	Disable *	•	^
МСРЗТ	ASB (LAN)	Enable *	•	
Current Connection	ASB (USB Type-A)	Enable *	•	
MCP31 StarPRNT Mode USB	ASB (USB Type-B)	Enable *	•	
Star MCP31	Asian Character (DBCS)	Double-Byte Character Set (DBCS)	•	
	Block Print Start Timing (Trigger)	Detect Page End (All I/F) *	•	
Connection Manager	Character Size	12 dots (Japanese)/ 13 dots (others/DBCS), 12 dc	•	
	<u>Character Size (Kanji)</u>	26dots *	•	
	<u>Code Page</u>	Normal*	Ŧ	
	Compression (Barcode)	Compress *	•	
			_	¥



8. Change 'Multi Bytes Character Code = Japanese' then click Store for save setting







Change Memory Switch Setting with mC-Print Utility on Mobile

1. Connect printer to mobile by Bluetooth and Open Star Quick Setup Utility Application on mobile (Download from App Store or Google Play)

Bluetooth		
Now discoverable as " 3anl <alore".< th=""><th></th><th>Star Quick Setup Utility</th></alore".<>		Star Quick Setup Utility
MY DEVICES		
AVH-P2450BT	Not Connected 🚺	STAR MICRONICS CO., LTD.
RAZR B1	Not Connected 🚺	5K+ E
mC-Print3-J0187	Connected 🚺	Downloads Everyone O



2. Click Selected Printer

4:41 🗖		¥ @∎
Star (Quick Setup Utility Ver.1.1.0	
8	Selected Printer 192.168.2.71 LAN / Model: mC-Print2 (MCP20) 00:11:62:1B:E2:05	"C-Print2
Top Men	u	
÷	Start Guide (Initial Settings)	
P	Printer Operation Check	
÷	Printer Settings	
	Online Manual	
i	Others	

^{3.} Choose the printer which connecting





4. Click Printer Setting

4:41 🗳	4:41 🗷 🖸 🖸 🔌 🔍 🔍 🔍 🔍			
Star	Quick Setup Utility Ver.1.1.0			
8	Selected Printer 192.168.2.71 LAN / Model: mC-Print2 (MCP20) 00:11:62:1B:E2:05	m C-Print2		
Top Men	u			
÷	Start Guide (Initial Settings)			
	Printer Operation Check			
ð	Printer Settings			
	Online Manual			
i	Others			

5. Click Memory Switch Setting

÷	Printer Settings	f
	Selected Printer mC-Print3-G0022 Bluetooth / Model: mC-Print3 (MCP31CB) 00:11:62:28:62:EF	"C-Print3
Print Set	tings	
≎ ⊠⊡	Memory Switch Settings	
° X	Logo Settings	
	Trigger Button Settings	
	Print Media Settings	



6. Change Character Set = Multi Byte (MBCS) and MBCS Font Set = Japanese then click Apply

← Memory Switch Settings		C
	Function Bit	
Region		
Character Set		Multi Byte (MBCS)
MBCS Font Set		Japanese
Special Region		Standard
	Single Byte (SBCS)	
	Multi Byte (MBCS)	
FACTORY DEFAULT		APPLY
7. LED on the printer will be flashing 1 time and t	he devices will appear 'Success' click OK. Finished	