

## How to assemble interface board into STAR Micronics Receipt Printer

\*This manual is using TSP650II or TSP654II

1. After picked up printer from the box, let's see at the behind of the printer then will see there's a slot for connecting interface board and there're 2 screws.



2. Remove 2 screws out from the unit.



3. Look at the printer inside, there's a black core which is plug with interface board.



4. Put the black core of the board interface facing down to connect to the black core of the printer side.



5. Then install 2 screws back into their original place, finished.

