

How to change density on SM-L300

1. Turn on mobile printer SM-L300
2. Press and hold the MODE & FEED buttons for 5 seconds.



3. Press the MODE button once to switch the menu item.
- Display: 1 Self Test → 2 System Setting



4. Press the FEED button once to get into the System Setting menu.
4.1 You will see present "Input Password 0000" in the LCD.



- 4.2 Press and hold the FEED button for 2 seconds to get into the menu.
- Display:

- 1 Density
- 2 Standby Time
- 3 Auto Off Time
- 4 Smart Power
- 5 Paper Type
- 6 BM Sensor
- 7 Printable Area
- 8 Factory Reset
- 9 Password
- 10 Previous Menu



5. Press the FEED button once to enter the menu

- Display: Density:
 0-Medium
 1-Low
 2-High
 3-Special
 0



6. Press the MODE button once to input the number 1, 2, 3 or 0, then press and hold FEED button to confirm the new setting and return to the previous menu.

